Some of the contents in this manual may differ from your device depending on the software of the device or your service provider.

To install Kies (PC Sync) Kies

1. Download the latest version of Kies from the Samsung website (**www.samsung.com/kies**) and install it on your PC.
2. Using a USB cable, connect your device to your PC. Samsung Kies will launch automatically.
   Refer to the Kies help for more information.

SAMSUNG

Samsung GALAXY Tab 7.0 Plus GT-P6210

user manual

Using this manual

Congratulations on your purchase of the Samsung mobile device. This powerful, "go anywhere" device, puts the best of the web and mobile computing at your fingertips in a lightweight, highly versatile platform that fits your active lifestyle. Built on the Google Android operating system, the Samsung mobile device gives you access to thousands of useful and entertaining applications to enrich your mobile web experience.

With integrated wireless access and a responsive touch screen, you can read books and newspapers on the go; stay up-to-date on the latest news, sports, and weather; manage your multimedia and business files; and browse the web for maps, business locations, and more.

Read me first

- Please read all safety precautions and this manual carefully before using your device to ensure safe and proper use.
- The descriptions in this manual are based on the default settings of your device.
- Images and screenshots used in this user manual may differ in appearance from the actual product.
- Content in this user manual may differ from the product, or from software provided by service providers or carriers, and is subject to change without prior notice. Refer to www.samsung.ca for the latest version of the user manual.
- Available features and additional services may vary by device, software, or service provider.
- Formatting and delivery of this user manual is based on Google Android operating systems and may vary depending on the user's operating system.

- Applications and their functions may vary by country, region, or hardware specifications. Samsung is not liable for performance issues caused by third-party applications.
- Samsung is not liable for performance issues or incompatibilities caused by edited registry settings or modified operating system software. Attempting to customize the operating system may cause your device or applications to work improperly.
- You may upgrade your mobile device's software by accessing www.samsung.ca.
- Software, sound sources, wallpapers, images, and other contents provided in this device are licenced for limited use between Samsung and their respective owners. Extracting and using these materials for commercial or other purposes is an infringement of copyright laws. Samsung is not liable for such copyright infringement by the user.
- Please keep this manual for future reference.

Instructional icons

Before you start, familiarize yourself with the icons you will see in this manual:

Warning—situations that could cause injury to yourself or others

Caution—situations that could cause damage to your device or other equipment

Note—notes, usage tips, or additional information

► **Refer to**—pages with related information; for example: ► p. 12 (represents "see page 12")

→ **Followed by**—the order of options or menus you must select to perform a step; for example: Open the application list and select **Settings** → **Wireless and networks** (represents **Settings**, followed by **Wireless and networks**)

[ ] **Square brackets**—device keys; for example: [⏻] (represents the Power/Reset/Lock key)

Copyright

Copyright © 2012 Samsung Electronics

This user manual is protected under international copyright laws.

No part of this user manual may be reproduced, distributed, translated, or transmitted in any form or by any means, electronic or mechanical, including photocopying, recording, or storing in any information storage and retrieval system, without the prior written permission of Samsung Electronics.

Trademarks

- SAMSUNG and the SAMSUNG logo are registered trademarks of Samsung Electronics.
- The Android logo, Google Search™, Google Maps™, Google Mail™, YouTube™, Android Market™, and Google Talk™ are trademarks of Google, Inc.
- Bluetooth® is a registered trademark of the Bluetooth SIG, Inc. worldwide.

- Oracle and Java are registered trademarks of Oracle and/or its affiliates. Other names may be trademarks of their respective owners.
- Windows Media Player® is a registered trademark of Microsoft Corporation.
- Wi-Fi®, Wi-Fi Protected Setup™, Wi-Fi Direct™, Wi-Fi CERTIFIED™, and the Wi-Fi logo are registered trademarks of the Wi-Fi Alliance.
- DivX®, DivX Certified®, and associated logos are trademarks of Rovi Corporation or its subsidiaries and are used under licence.
- All other trademarks and copyrights are the property of their respective owners.

ABOUT DIVX VIDEO

DivX® is a digital video format created by DivX, LLC, a subsidiary of Rovi Corporation. This is an official DivX Certified® device that plays DivX video. Visit www.divx.com for more information and software tools to convert your files into DivX videos.

DivX Certified® to play DivX® video up to HD 720p, including premium content

ABOUT DIVX VIDEO-ON-DEMAND

This DivX Certified® device must be registered in order to play purchased DivX Video-on-Demand (VOD) movies. To obtain your registration code, locate the DivX VOD section in your device setup menu. Go to vod.divx.com for more information on how to complete your registration.

Contents

Assembling 10
Unpack 10
Charge the battery 10
Insert a memory card (optional) 13

Getting started 16
Turn your device on and off 16
Get to know your device 17
Use the touch screen 21
Get to know the Home screen 23
Access applications 27
Customize your device 28
Enter text 31

Web 37
Browser 37
Pulse 41
Play Store 42
YouTube 43
Maps 43
Latitude 45
Places 46
Navigation 46
Samsung Apps 47

Communication 49
Gmail 49
Email 51

Talk 53
Social Hub 55

Entertainment 56
Music player 56
Camera 58
Video player 68
Gallery 69
Photo editor 71

Personal information 73
Contacts 73
Calendar 76
Memo 77

Connectivity 79
PC connections 79
Wi-Fi 81
Wi-Fi Direct 83
Bluetooth 84
AllShare 86
GPS 89
VPN connections 90

Settings 92
Access the Settings menu 92
Wireless and networks 92
Sound 94
Screen 94
Power saving mode 95
Location and security 96

Applications 98
Accounts and sync 99
Motion 99
Privacy 99
Storage 100
Language and input 100
Accessibility 104
Date and time 105
About device 105

Tools 106
Alarm 106
Calculator 107
Downloads 107
eBook 107
Google Search 109
My files 109
Pen memo 112
Polaris Office 112
Voice Search 114
World Clock 114

Troubleshooting 116

Index 119

Assembling

Unpack

Check your product box for the following items:

- Mobile device
- Quick start guide

Use only Samsung-approved software. Pirated or illegal software may cause damage or malfunctions that are not covered by your manufacturer's warranty.

- The items supplied with your device and available accessories may vary depending on your region or service provider.
- You can purchase additional accessories from your local Samsung dealer.
- The supplied accessories perform best for your device.
- Accessories other than the supplied ones may not be compatible with your device.

Charge the battery

Your device has a built-in battery. Before using the device for the first time, you must charge the battery.

Use only Samsung-approved chargers. Unauthorized chargers can cause batteries to explode or damage your device.

- Charge the battery only with a charger. You cannot charge the battery with the USB cable.
- When your battery is low, the device will emit a warning tone and display a low battery message. The battery icon will also be empty. If the battery level becomes too low, the device will automatically power off. Recharge your battery to continue using your device.
- If the battery is completely discharged, you cannot turn on the device, even with the USB power adapter connected. Allow a depleted battery to charge for a few minutes before you try to turn on the device.

1 Connect the USB cable to the USB power adapter and then plug the end of the USB cable into the multifunction jack.

The shape of the USB power adapter may differ depending on your region.



Connecting the USB cable improperly may cause serious damage to the device or USB power adapter. Any damage caused by misuse is not covered by the warranty.

2 Plug the USB power adapter into a power outlet.

- You can use the device while it is charging, but it may take longer to fully charge the battery.
- While the device is charging, the touch screen may not function due to an unstable power supply. If this happens, unplug the USB power adapter from the power outlet or unplug the USB cable from the device.
- While charging, the device may heat up. This is normal and should not affect your device's lifespan or performance.
- If your device is not charging properly, bring your device and the charger to a Samsung Service Centre.

3 When the battery is fully charged, first unplug the USB power adapter and USB cable from the device and then from the power outlet.

To save energy, unplug the USB power adapter when not in use. The USB power adapter does not have a power switch, so you must unplug the USB power adapter from the outlet when not in use to avoid wasting power. The USB power adapter should remain close to the socket when in use.

Insert a memory card (optional)

To store additional files, you must insert a memory card. Your device accepts microSD™ or microSDHC™ memory cards with maximum capacity of 32 GB (depending on memory card manufacturer and type).

Samsung uses approved industry standards for memory cards, but some brands may not be fully compatible with your device. Using an incompatible memory card may damage your device or the memory card and can corrupt data stored on the card.

- Your device supports only the FAT file structure for memory cards. If you insert a card formatted with a different file structure, your device will ask you to reformat the memory card.
- Frequent writing and erasing of data will shorten the lifespan of memory cards.
- When you insert a memory card in your device, the file directory of the memory card will appear in the extStorages folder under the internal memory.

1 Open the cover of the memory card slot.

2 Insert a memory card with the gold-coloured contacts facing down.



3 Push the memory card in the memory card slot until it locks in place.

4 Close the memory card cover.

› Remove the memory card

Before removing a memory card, first unmount it for safe removal.

1 Open the application list and select **Settings** → **Storage** → **Unmount SD card**.

2 Open the memory card cover.

3 Push the memory card gently until it disengages from the device.

4 Remove the memory card.

Do not remove a memory card while the device is transferring or accessing information, as this could result in loss of data or damage to the memory card or device.

› Format the memory card

Formatting your memory card on a PC may cause incompatibilities with your device. Format the memory card only on the device.

Open the application list and select **Settings** → **Storage** → **Format SD card** → **Format SD card** → **Delete all**.

Before formatting the memory card, remember to make backup copies of all important data stored on your device. The manufacturer's warranty does not cover loss of data resulting from user actions.

Getting started

Turn your device on and off

To turn on your device, press and hold [⏻]. When you turn on your device for the first time, follow the on-screen instructions to set up your device.

To turn off your device, press and hold [⏻] and select **Power off** → **OK**.

Follow all posted warnings and directions from authorized personnel in areas where the use of wireless devices is restricted, such as aeroplanes and hospitals.

› Switch to Airplane mode

In Airplane mode, you can disable all wireless connections and use non-network services in areas where wireless devices are prohibited, such as airplanes and hospitals.

To activate Airplane mode, go to **Settings** → **Wireless and networks** → **Airplane mode** → **OK**.

To deactivate Airplane mode and use wireless connections, go to **Settings** → **Wireless and networks** and clear the check box next to **Airplane mode**.

Get to know your device

› Device layout





Number	Function
1	Earpiece
2	Proximity sensor/ Light sensor
3	Speaker
4	Microphone
5[1]	Microphone
6	Front camera lens
7	Power/Reset/Lock key
8	Volume key

1. Active only when you use the speakerphone feature or record videos.

Number	Function
9	Multifunction jack
10 [2]	GPS antenna
11	Rear camera lens
12	Flashbulb
13 [3]	Headset jack
14	Memory card slot

› Keys

Key		Function
	Power/ Reset[4]/ Lock	Turn on the device (press and hold); Access the quick menus (press and hold); Reset the device (press and hold for 10-15 seconds); Lock the touch screen.
	Volume	Adjust the device's volume.

2. Do not touch or cover the antenna area with your hands or other objects while using the GPS functions.
3. Connecting a headset to your device improperly can damage the headset jack or the headset.
4. If your device has fatal errors or hang-ups, or freezes, you may need to reset the device to regain functionality.

› Indicator icons

Icons shown on the bottom of the screen may vary depending on your region or service provider.

Icon	Definition
	Open WLANs available
	WLAN connected
	Bluetooth activated
	Receiving GPS data
	Synchronized with the web
	Uploading data
	Downloading data
	Connected to PC
	New email message
	New Gmail message
	Alarm activated
	Event notification
	Flight mode activated
	Music playback in progress

Icon	Definition
	Error occurred or caution required
[1]	Battery power level
	Unable to charge
	Current time

Use the touch screen

Your device's touch screen lets you easily select items or perform functions. Learn basic actions to use the touch screen.

- To avoid scratching the touch screen, do not use sharp tools.
- Do not allow the touch screen to come into contact with other electrical devices. Electrostatic discharges can cause the touch screen to malfunction.
- Do not allow the touch screen to come into contact with water. The touch screen may malfunction in humid conditions or when exposed to water.

- For optimal use of the touch screen, remove the screen protection film before using your device.
- Your touch screen has a layer that detects small electrical charges emitted by the human body. For best performance, tap the touch screen with your fingertip. The touch screen will not react to touches of sharp tools, such as a stylus or pen.

1. If you use a charger that is not approved by Samsung, this indicator will not appear.

You can control your touch screen with the following actions:

- Tap: Touch once with your finger to select or launch a menu, option, or application.
- Drag: Tap and drag your finger up, down, left, or right to move to items on lists.
- Tap and hold: Tap an item and hold it for more than 2 seconds to open a pop-up option list.
- Drag and drop: Tap and hold your finger on an item, and then drag your finger to move the item.
- Double-tap: Tap twice quickly with your finger to zoom in or out while viewing photos.

› Rotate the touch screen

Your device has a built-in motion sensor that detects its orientation. If you rotate the device, the interface will automatically rotate according to the orientation.

To set the interface to keep the orientation, select the right side of the system bar and then select **Auto Rotation** on the notifications panel.

› Lock or unlock the touch screen

When you do not use the device for a specified period, your device turns off the touch screen and automatically locks the touch screen to prevent any unwanted device operations. To manually lock the touch screen, press [⏻].

To unlock, turn on the screen by pressing [⏻], and drag in any direction until it reaches the border of the circle.

You can activate the screen lock feature to prevent others from using or accessing your personal data and information saved in your device. ► p. 30

Get to know the Home screen

When the device is in Idle mode, you will see the Home screen. From the Home screen, you can view indicator icons, widgets, shortcuts to applications, and other items. Scroll left or right to a panel of the Home screen.



The above screen may differ depending on your region or service provider.

Number	Function
1	Search for applications and files in your device and specific data on the web with the Google Search widget.
2	Select a dot at the top of the screen to move directly to the corresponding screen.
3	Customize the Home screen.

Number	Function
4	Access the application list.
5	System bar (See the following section).

System bar

From the system bar, you can quickly navigate screens, access applications, view system information, and more.



Number	Function
1	Capture the current screen and open the drawing pad; capture the current screen, save as an image file and copy to the clipboard (tap and hold).
2	Return to the previous screen.
3	Return to the Home screen; access the task manager (tap and hold).
4	Open the list of recent applications; access the application list (tap and hold).
5	Display indicator icons and your device's current status; open the notifications panel.
6	Open the mini apps panel.

› Add items to the Home screen

You can customize the Home screen by adding shortcuts to applications or items in applications, widgets, or folders.

To add an item to the Home screen,

1. From the Home screen, select .
2. Select an item category.
   - **Widgets**: Add widgets. Widgets are small applications that provide convenient functions and information.
   - **App shortcuts**: Add shortcuts to applications.
   - **Wallpapers**: Set a background image.
   - **More**: Add shortcuts to items, such as bookmarks, contacts, and maps.
3. Select an item to add to the Home screen.

› Move items on the Home screen

1. Tap and hold an item to move until the Home screen grid appears.
2. Drag the item to the location you want.

› Remove items from the Home screen

1. Tap and hold an item to remove.
   The trash bin appears at the top right of the Home screen.
2. Drag the item to the trash bin.
3. When the item turns red, release the item.

› Add a shortcut to an application

1 From the application list, tap and hold an application icon and drag it to a Home screen panel at the bottom of the screen.

The shortcut icon for the application is added to the Home screen.

2 Move the icon to the location you want or move it to another panel of the Home screen.

› Use the notifications panel

From the Home screen or while using an application, select the right side of the system bar, and then select an option on the notifications panel.

You can view the device's current status and use the following options:

- **Wi-Fi**: Activate or deactivate the WLAN feature.
- **Notifications**: Set the device to alert you for various events.
- **GPS**: Activate or deactivate the GPS feature.
- **Sound/Vibration**: Activate or deactivate Vibration mode.
- **Auto Rotation**: Activate or deactivate the auto rotation.
- **Bluetooth**: Activate or deactivate the Bluetooth wireless connection feature.
- **Airplane mode**: Activate or deactivate Airplane mode.

You can also adjust the display brightness or access the settings menu.

Available options may vary depending on your region or service provider.

Access applications

1 From the Home screen, select **Apps** to access the application list.

2 Select **All** to view all applications or **My apps** to view downloaded applications only.

3 Select an application.

4 Select ⮌ to return to the previous screen; Select ⌂ to return to the Home screen.

Before using location services, such as map and navigation applications, or internet services, ensure that the wireless connection is active.

› Access recent applications

1 Select ▭ to view the applications you have accessed recently.

2 Select an application.

› Use the task manager

Your device is a multitasking device. It can run more than one application at the same time. However, multitasking may cause hang-ups, freezing, memory problems, or additional power consumption. To avoid these problems, end unnecessary programs using the task manager.

1 Tap and hold ⌂.

2 To close an application, select **End**.
To close all active applications, select **End all**.

Customize your device

Get more from your device by customising it to match your preferences.

› Change the language of the display

1. Open the application list and select **Settings** → **Language and input** → **Select language**.
2. Select the language you want.

› Set the current time and date

1. Open the application list and select **Settings** → **Date and time**.
2. Select your time zone, set the time and date, and change other options.

› Turn the touch tone on or off

Open the application list and select **Settings** → **Sound** → **Audible selection**.

› Adjust the device's volume

1. Press the Volume key up or down.
2. Select and drag the sliders to adjust the volume level for media sounds, notifications and alarm sounds.

› Switch to Silent mode

From the Home screen or while using an application, select the right side of the system bar and then select **Sound** on the notifications panel.

You can set the device to alert you to various events in Silent mode. Open the application list and select **Settings** → **Sound** → **Vibrate** → **Always** or **Only in Silent mode**. When you switch to Silent mode, **Vibration** will appear in place of **Silent** on the notifications panel.

› Select a wallpaper for the Home screen

1 From the Home screen, select → **Wallpaper**.

2 Select an image folder.
If you selected **Gallery** or **Wallpaper**, select **Home screen wallpaper**.

3 Select an image.

4 If you selected a live wallpaper, select **Set wallpaper**.
If you selected an image from Gallery, move or resize the rectangle to select a portion of the image, and then select **OK**.

Samsung is not responsible for any use of default images or wallpapers provided on your device.

› Activate animation for switching windows

You can set a transition effect between windows while using the device.

1 Open the application list and select **Settings** → **Screen** → **Animation**.

2 Select an animation option.

› Adjust the brightness of the display

1. Open the application list and select **Settings** → **Screen** → **Brightness**.
2. Clear the check box next to **Automatic brightness**.
3. Drag the slider to adjust the level of brightness.
4. Select **OK**.

The brightness level of the display will affect how quickly the device consumes battery power.

› Set a screen lock

You can lock the touch screen with an unlock pattern or password to prevent unauthorized people from using the device without your permission.

- Once you set a screen lock, your device will require an unlock code each time you turn it on or unlock the touch screen.
- If you forget your PIN or password, bring your device to a Samsung Service Centre to reset it.
- Samsung is not responsible for any loss of security codes or private information or other damages caused by illegal software.

Set an unlock pattern

1. Open the application list and select **Settings** → **Location and security** → **Configure lock screen** → **Pattern**.
2. See the on-screen instructions and example patterns and select **Next**.

3 Draw a pattern by dragging your finger to connect at least 4 dots and select **Continue**.

4 Draw the pattern again to confirm and select **Confirm**.

Set an unlock PIN code

1 Open the application list and select **Settings** → **Location and security** → **Configure lock screen** → **PIN**.

2 Enter a new PIN (numeric) and select **Continue**.

3 Enter the PIN again and select **OK**.

Set an unlock password

1 Open the application list and select **Settings** → **Location and security** → **Configure lock screen** → **Password**.

2 Enter a new password (alphanumeric) and select **Continue**.

3 Enter the password again and select **OK**.

Enter text

You can enter text by selecting characters on the virtual keypad, inputting handwriting on the screen, or speaking words into the microphone.

You cannot enter text in some languages. To enter text, you should change the writing language to one of the supported languages. ► p. 100

› Change the keyboard type

You can change the keyboard type. Select on the system bar and select a keyboard type (Android keyboard, Samsung keypad, or Swype keyboard).

You can also enter text with your voice. Select and a voice input option, according to the language you want to use.

› Enter text using the Android keyboard

Enter text by selecting alphanumeric keys and you can use the following keys:

Number	Function
1	Change case.
2	Switch between Number/Symbol mode and ABC mode.
3	Move the cursor to the next text input field.
4	Clear your input.
5	Start a new line or field.
6	Insert an emoticon; open the emoticon list (tap and hold).

Number	Function
❼	Enter text by voice; change the input language or access the keyboard settings (tap and hold). This feature may be unavailable depending on the selected input language.
❽	Insert a space.

› Enter text using the Samsung keypad

Enter text by selecting alphanumeric keys and you can use the following keys:



Number	Function
❶	Minimize the virtual keypad.
❷	Move the cursor to the next text input field.
❸	Change case.
❹	Switch between Number/Symbol mode and ABC mode.
❺	Access the keypad settings; change the keypad type or activate the voice input feature (tap and hold).
❻	Insert a space.

Number	Function
⑦	Clear your input.
⑧	Start a new line.
⑨	Attach an item.
⑩	Switch to the handwriting keypad.
⑪	Insert an emoticon; open the emoticon list (tap and hold).

You can activate XT9 predictive text mode by selecting → **XT9**. When you enter the first three letters of a word, the alternate word list appears.

You can use a variety of gestures in Handwriting mode to edit text. For more information about gestures, select → **Handwriting settings** → **Gesture guide**.

› Enter text using the Swype keypad

1. Select the first character of a word and drag your finger to the second character without releasing the finger from the screen.
2. Continue until you have finished the word.



3 Release the finger on the last character.

4 When the word displays correctly, select ⎵ to insert a space. If the correct word does not display, select an alternative word from the list that appears.

5 Repeat steps 1-4 to complete your text.

- You can also tap the keys to enter text.
- You can tap and hold a key to enter characters on the upper half of the key. When you tap and hold a key until the character list appears, you can enter special characters and symbols.

You can also use the following keys:



Number	Function
1	Change the input language (tap and hold).
2	Move the cursor to the next text input field.
3	Change case.
4	Enter the recommended word or add a new word to the dictionary; access the keypad settings (tap and hold).
5	Switch between Symbol mode and ABC mode.
6	Switch between Number mode and Edit mode.

Number	Function
❼	Clear your input.
❽	Start a new line.
❾	Minimize the virtual keypad.
❿	Enter text by voice. This feature may be unavailable depending on the selected input language.
⓫	Insert a space.

› Copy and paste text

While you are entering text, you can use the copy and paste feature to use text in other applications.

1. Tap and hold a word.
2. Drag (◀) or ▶ to select the text you want.
3. Select to copy, or to cut the text onto the clipboard.
4. In another application, tap and hold the text input field.
5. Select **Paste** to insert the text from the clipboard into the text input field.

Web

Browser

Learn to access and bookmark your favourite web pages.

- The web browser menu may be labeled differently depending on your region or service provider.
- Available icons may vary depending on your region or service provider.

› Browse web pages

1 Open the application list and select **Browser** to launch your homepage.

To access a specific web page, select the URL input field, enter the web address of the web page, and select .

2 Navigate web pages with the following keys:



The above screen may differ depending on your region or service provider.

Number	Function
1	Close the current tab.
2	Move backward or forward to web pages in history.
3	Reload the current web page; While the device is loading web pages, this icon changes to ✕.
4	Open a new tab.
5	Search for information.
6	Access a list of web browser options.
7	Open a list of saved bookmarks and recent internet history.
8	Bookmark the current web page.

While browsing the web page, use the following options:

- To zoom in, place two fingers on the screen and spread them apart. To zoom out, move your fingers closer together. You can also double-tap the screen.
- To open a new tab, select → **New tab**.
- To open a new tab without saving cookies, select → **New incognito tab**.
- To search for text on the web page, select → **Find on page**.
- To send the web address of the web page to others, select → **Share page**.
- To save the current web page and read it offline later, select → **Save page**.

- To view page details, select → **Page info**.
- To view the items downloaded from the web, select → **Downloads**.
- To print the web page using a WLAN or USB connection, select → **Print**. Your device is compatible only with some Samsung printers.
- To customize browser settings, select → **Settings**.

› Search for information by voice

This feature may be unavailable depending on your region or service provider.

1. Open the application list and select **Browser**.
2. Select .
3. Select and say a keyword into your device's microphone.
   The device searches for information and web pages related with the keyword.

› Open multiple pages

You can open multiple pages and switch back and forth between them.

1. Open the application list and select **Browser**.
2. Select to open a new tab.
3. Access another web page on the new tab.
4. To switch back and forth between currently open tabs, select the title of a tab.

› Bookmark your favourite web pages

If you know the web address of the web page, you can manually add a bookmark.

Add a bookmark

1. Open the application list and select **Browser**.
2. Select → .
   You can also select ★ to bookmark the current web page.
3. Enter a page title and a web address.
4. Select the **Bookmarks** drop-down menu and select a bookmark location to add (if necessary).
5. Select **OK**.

To use bookmark options, select , tap and hold a bookmark:

- To open the web page in the current tab, select **Open**.
- To open the web page in a new tab, select **Open in new tab**.
- To edit the bookmark, select **Edit bookmark**.
- To add the bookmark shortcut to the Home screen, select **Add shortcut to home**.
- To send the web address of the web page to others, select **Share link**.
- To copy the web address of the web page, select **Copy link URL**.
- To delete the bookmark, select **Delete bookmark**.
- To use the web page as your homepage of the browser, select **Set as homepage**.

Create a bookmark folder

1. Open the application list and select **Browser**.
2. Select → → **New folder**.
3. Enter a name for the bookmark folder and select **Done**.

› Access recent history

1. Open the application list and select **Browser**.
2. Select → **History**.
3. Select a web page to access.

Pulse

You can use the Pulse reader to add feeds for your favourite news topics and read news articles on your device.

› Read feeds

1. Open the application list and select **Pulse**.
2. If you are launching this application for the first time, select **OK** to clear the hint.
3. Select to update feeds.
   To read the feeds you added to your favourite list, select .me.
4. Scroll up or down to select a feed source.
5. Scroll left or right and select a feed.
6. While reading a feed, use the following options:
   - To save a story, select .
   - To upload a feed to community websites, select f or .
   - To send a feed to others, select .
   - To return to a feed list, select .

› Manage feed sources

1. Open the application list and select **Pulse**.
2. Select to view the feed source list.
3. Select or to add or delete a feed source.

Play Store

Your device's functionality can be extended by installing additional applications. Google Play (formerly Android Market) provides you an easy and quick way to shop for games and mobile applications.

This feature may be unavailable depending on your region or service provider.

› Download and install an application

1. Open the application list and select **Play Store**.
2. If you are launching this application for the first time, select **Accept**.
3. Search for a file or application and download it.

› Uninstall an application

1. Open the application list and select **Play store**.
2. Select .
3. Select the item you want to delete.
4. Select **Uninstall**.

YouTube

Learn to view and upload videos via YouTube.

This feature may be unavailable depending on your region or service provider.

› Watch videos

1. Open the application list and select **YouTube**.
2. Select a video from the list.
3. Tap a video screen and select to display a full screen.
4. Control playback with the virtual keys.

› Upload videos

1. Open the application list and select **YouTube**.
2. Select **Your Channel**.
3. Select your Google account if it is linked to YouTube. You can also select **Add account** and set up an account to sign in YouTube.
4. Select → **Upload** and then select a video.
5. Enter details for the upload and select **Upload**.

Maps

Learn to use Google Maps™ to find your location, search the map for streets, cities, or countries, and get directions.

This feature may be unavailable depending on your region or service provider.

› Search for a specific location

1. Open the application list and select **Maps**.
2. If you are launching this application for the first time, select **OK**.
   The map will display your current location.
3. Select **Search Maps**.
4. Enter a keyword for the location and select .
   To search for a location by voice, select .
5. Select the location you want to view details.
   - To view your current location, select .
   - To switch to a compass view of the map that changes orientation when you move the device, select .
   - To search for a place around you, select .
   - To get directions to a specific destination, select .
   - To add layers to the map, select .
   - To access a list of other options, select .
   - To zoom in, place two fingers on the screen and spread them apart. To zoom out, move your fingers closer together.
   - To add a star to the location, select the balloon of the location name → .

› Get directions to a specific destination

1. Open the application list and select **Maps**.
2. Select .

3 Enter the addresses of the starting location and the ending location.

To select an address from your contact list or starred places, or point the location on the map, select → **Contacts**, **Point on map** or **My Places**.

4 Select a travel method (car, bus, bicycle or walk) and select **Go**.

The route is indicated on the map. Depending on the selected travel method, you may see multiple routes.

5 When you are finished, select → **Clear Map**.

Latitude

Learn to share your location with your friends and view friends' locations via Google Latitude™.

This feature may be unavailable depending on your region or service provider.

1 Open the application list and select **Latitude**.

The device automatically joins Latitude.

2 Select → **Add friends** → **Select from Contacts** or **Add via email address**.

3 Select a friend you want to add, or enter an email address and select **Send**.

4 Select **Yes**.

When your friend accepts your invitation, you can share locations.

5 Select a friend from the list.

Your friends' locations are marked with their photos on the map.

Places

Learn to search for a place around you.

This feature may be unavailable depending on your region or service provider.

1. Open the application list and select **Places**.
2. Select a category.
   Your device searches for places around your current location that are related to the category.
3. Select a place name to view its details.
4. While viewing information, use the following options:
   - To view the place on the map, select **Map**.
   - To view the route to the place, select **Directions**.

Navigation

Learn to use the GPS navigation system to find and show your destination with voice guidance.

- Navigation maps, your current location, and other navigational data may differ from actual location information. You should always pay attention to road conditions, traffic, and any other factors that may affect your driving and follow all safety warnings and regulations while driving.
- This feature may be unavailable depending on your region or service provider.

1 Open the application list and select **Navigation**.

2 If you are launching this application for the first time, select **Accept**.

3 Enter your destination by using one of the following methods:

- **Speak Destination**: Speak your destination such as "Navigate to destination."
- **Type Destination**: Enter your destination with the virtual keypad.
- **Contacts**: Select your destination from addresses of your contacts.
- **Starred Places**: Select your destination from the list of your starred places.

4 Follow the on-screen instructions to use the navigation service.

Samsung Apps

Samsung Apps allows you to simply and easily download an abundance of applications directly to your device. Featuring a wealth of games, news, reference, social networking, navigation, health related applications and more, Samsung Apps gives you instant access to a huge choice of mobile experience.

Your device gets smarter with fully optimized applications from Samsung Apps. Explore amazing applications and make your mobile life even better.

- This feature may be unavailable depending on your region or service provider.
- For details, please visit www.samsungapps.com.

1 Open the application list and select **Samsung Apps**.

2 If you are launching this application for the first time, select a region → **OK**. Then read the terms and conditions and select **Accept**.

3 Search for and download applications as desired.

Communication

Gmail

You can retrieve new email messages from Gmail™ (Google Mail) to your Inbox. When you access this application, the Inbox screen appears. The total number of unread messages displays in the title bar and unread messages display in bold.

- This feature may be unavailable depending on your region or service provider.
- This menu may be labeled differently depending on your region or service provider.

› Send an email message

1. Open the application list and select **Gmail**.
2. Select .
3. Enter a name or address in the recipient field.
4. Enter a subject and message.
5. Select → a file to attach an image file.
6. Select **Send** to send the message.

› View an email message

1. Open the application list and select **Gmail**.
2. Select an email message.

From the message view, use the following options:

- To move to the previous or next message, select **Older** or **Newer**.
- To search for an email message, select .
- To create a new message, select .
- To archive the message, select .
- To delete the message, select .
- To make the message as unread, select → **Mark unread**.
- To mark the message as important, select → **Mark important**.
- To add a label to a message, select → **Change labels**.
- To register the message to the spam list, select → **Report spam**.
- To hide the message, select → **Mute**.
- To reload the messages, select → **Refresh**.
- To customize the email settings, select → **Settings**.
- To reply to the message, select .
- To reply to the message including all recipients, select .
- To forward the message to other people, select .
- To add a star to the message, select .
- To view an attachment, select **View**. To save it to your device, select **Save**.

Available options may vary depending on the account.

Email

Learn to send or view email messages via your personal or company email account.

› Set up an email account

1. Open the application list and select **Email**.
2. Enter your email address and password.
3. Select **Next** (for general email accounts) or **Manual setup** (for other company email accounts).
4. Follow the on-screen instructions.
5. To add more email accounts, select → **Settings** → **Add account** and repeat steps 2-4.

When you are finished setting up the email account, the email messages are downloaded to your device. If you have created more than two accounts, you can switch between email accounts; select an account name at the top left of the screen and select the one you want to retrieve messages from.

› Send an email message

1. Open the application list and select **Email** → an email account.
2. Select .
3. Add recipients of your message.
   - Enter email addresses manually, separating them with a semicolon.
   - Select email addresses from the lists by selecting .

4 Select **+Cc/Bcc** and add more recipients.
You can also add yourself to the recipient list by selecting **+Me**.

5 Select the subject field and enter a subject.

6 Select the text input field and enter your email text.
You can insert an image, contact, calendar, memo, or location by selecting .

7 Select → file to attach a file.

8 Select **Send** to send the message.

If you are offline or outside your service area, the message will be held in the outbox until you are online and in your service area.

› View an email message

When you open an email account, you can view previously retrieved emails offline or connect to the email server to view new messages. After retrieving email messages, you can view them offline.

1 Open the application list and select **Email** → an email account.

2 Select to update the message list.

3 Select an email message.

From the message view, use the following options:

- To move to the previous or next message, select ‹ or ›.
- To search for an email message, select .
- To reload the messages, select .
- To create a new message, select .

- To reply to the message, select .
- To forward the message to other people, select .
- To delete the message, select .
- To make the message as unread, select → **Mark as unread**.
- To move the message to another folder, select → **Move**.
- To view the messages by category, select → **List by**.
- To change the view mode, select → **View mode**.
- To change the background colour, select → **Background color**.
- To print the message using a WLAN or USB connection, select → **Print**. Your device is compatible only with some Samsung printers.
- To customize the email settings, select → **Settings**.
- To add a star to the message, select ☆.
- To save an attachment to your device, select .

Some options appear only in landscape view.

Talk

Learn to chat with friends and family via Google Talk™.

This feature may be unavailable depending on your region or service provider.

› Set your status

1. Open the application list and select **Talk**.
2. Enter your Google account and password and select **Sign in** (if necessary).
3. Customize your status, image, and message to display.

› Add friends to your friend list

1. Open the application list and select **Talk**.
   The friend list shows all of your Google Talk contacts at a glance.
2. Select .
3. Enter an email address of the friend and select **Send invitation**.

When your friend accepts the invitation, the friend is added to your friend list.

› Start a chat

1. Open the application list and select **Talk**.
2. Select a friend from the friend list. The chat screen opens.
3. Enter your message and select .
   To add a friend to a chat, select → **Add to chat**.
4. To end the chat, select .

Social Hub

Learn to access Social Hub™, the integrated communication application for email, contacts or calendar information. Visit socialhub.samsungapps.com for more details.

1. Open the application list and select **Social Hub**.
2. If you are launching this application for the first time, add an account or skip it for a later setup.
3. Select a category at the top left of the screen.
4. Check and use contents delivered from Social Hub.

Entertainment

Music player

Learn to listen to your favourite music while on the go with the music player. The music player supports the following file formats: mp3, aac, ogg, wma, amr, m4a, mp4, flac, wav, mid, mxmf, xmf, rtttl, rtx, ota, imy (Codec: MP3, AAC, AAC+, eAAC+, FLAC, WMA, Vorbis, Midi, AMR NB/WB, AC3 (only with Video), WAV).

- You can also play music files in the following formats if you open them from My files or the web browser: mid, xmf, rtttl, imy, rtx, ota, amr, wav, mxmf.
- Some file formats are not supported depending on the software of the device.
- If the file size exceeds the available memory, an error can occur when you open files.
- Playback quality may vary by content type.
- Some files may not play properly depending on how they are encoded.

› Add music files to your device

Start by transferring files to your device or memory card:

- Download from the wireless web. ► p. 37
- Download from a PC with Samsung Kies. ► p. 79
- Receive via Bluetooth. ► p. 86
- Copy to your memory card. ► p. 80
- Synchronize with Windows Media Player 11. ► p. 80

› Play music

After transferring music files to your device or memory card,

1. Open the application list and select **Music Player**.
2. Select a music category → a music file.
3. Tap the music player field.
4. Control playback with the virtual keys.

While playing music, use the following options:

- To delete a music file, select → **Delete**.
- To send a music file to others, select → **Share via**.
- To set a music file as an alarm tone, select → **Set as alarm tone**.
- To customize your music player, select → **Settings**.

- You can control the music player with a headset. In Idle mode, press and hold the headset button to launch the music player. Press the headset button to start or pause playback.
- You can experience virtual 5.1 surround sound when listening to multichannel content, such as DVD movies.

› Create a playlist

1. Open the application list and select **Music player**.
2. Select → **New playlist**.
3. Enter a title for your new playlist and select **OK**.
4. To add music files to the playlist, select ⊕ next to the music files you want to add and select **Done**.

› Customize music player settings

1 Open the application list and select **Music player**.

2 Select → **Settings**.

3 Adjust the following settings to customize your music player:

Option	Function
Equalizer	Select a default equalizer type.
Sound effects	Select a sound effect.
Music auto off	Set the music player to automatically turn off after a specified length of time.
Music menu	Select music categories to display on the music library screen.

Camera

Learn how to capture and view photos and videos. You can take photos at resolutions up to 2048 x 1536 pixels (3.2 megapixels) and videos at resolutions up to 1280 x 720 pixels.

- The camera automatically turns off when you do not use it for a specified period.
- The memory capacity may differ depending on the shooting scene or shooting conditions.

› Capture a photo

1 Open the application list and select **Camera** to turn on the camera.

2 Aim the lens at the subject and make any necessary adjustments.

Number	Function
1	Use camera shortcuts. • : Change the flash settings. • : Switch between the front and rear camera. • : Change the shooting mode. • : Select the length of the delay before the camera takes a photo. • : Adjust the exposure value. You can add or remove shortcuts to frequently used options. ► p. 63
2	Change the camera settings.
3	View the default storage location.
4	Switch to the camcorder.
5	Capture a photo.
6	Open the image viewer to view photos or videos you captured or recorded.

3 Tap where you want to focus on the preview screen.
The focus frame moves to the place you tap and changes to green when the subject is in focus.

4 Select to take a photo.
The photo is saved automatically.

After taking photos, select the image viewer icon to view the captured photos.

- To view more photos, scroll left or right. You can also tap the screen and scroll through the thumbnails of photos at the bottom of the screen.
- To zoom in, place two fingers on the screen and spread them apart. To zoom out, move your fingers closer together. You can also double-tap the screen.
- To send a photo to others, select **Share via**.
- To set a photo as wallpaper or an image for a contact, select **Set as**.
- To delete a photo, select **Delete**.
- To access Gallery, select **Go to Gallery**.

› Capture a photo by using preset options for various scenes

Your camera provides you with predefined settings for various scenes. You can simply select the proper mode for your shooting condition and subjects. For example, when you take photos at night, select the night mode that uses an extended exposure.

1 Open the application list and select **Camera** to turn on the camera.

2 Select → **Scene mode** → a mode.

3 Make any necessary adjustments.

4 Select to take a photo.

› Capture a photo in Self shot mode

You can take photos of yourself conveniently using the front camera lens.

1 Open the application list and select **Camera** to turn on the camera.

2 Tap or select → **Self portrait**.

3 Make any necessary adjustments.

4 Select to take a photo.

› Capture a photo in Smile shot mode

Your camera can recognize people's faces and help you take photos of their smiling faces.

1 Open the application list and select **Camera** to turn on the camera.

2 Tap → **Smile shot** or select → **Shooting mode** → **Smile shot**.

3 Make any necessary adjustments.

4 Aim the camera lens at your subject and select .
Your device recognizes people in an image and detects their smiles. When the subject smiles, the device automatically takes a photo.

› Capture a panoramic photo

You can take wide panoramic photos using Panorama shooting mode. This mode is convenient for photographing landscapes.

1. Open the application list and select **Camera** to turn on the camera.
2. Tap → **Panorama** or select → **Shooting mode** → **Panorama**.
3. Make any necessary adjustments.
4. Select to take the first photo.
5. Slowly move the device in any direction and align the green frame with the viewfinder.
   When you have aligned the green frame and viewfinder, the camera will automatically take the next photo.
6. Repeat step 5 six more times to complete the panoramic photo or, to stop the image capture and save the file before you have taken 8 frames, tap .

› Capture a photo of action

You can capture shots of a moving subject and then combine them into a single photo that shows the action.

1. Open the application list and select **Camera** to turn on the camera.
2. Tap → **Action shot** or select → **Shooting mode** → **Action shot**.
3. Make any necessary adjustments.
4. Select to take the first photo.
5. Move the device to follow the moving subject.
   The device automatically takes the next photos.
6. Continue to follow the subject until the device has captured all the shots necessary for the action photo.

› Customize camera settings

Before taking a photo, select ⚙ to access the following options:

Option	Function
Edit shortcuts	Edit shortcuts to frequently used options.
Self-portrait	Switch between the front and rear camera lenses.
Flash	Change the flash setting; You can manually turn the flash on or off, or set the camera to automatically use the flash when needed.
Shooting mode	Change the shooting mode.
Scene mode	Change the scene mode.
Exposure value	Adjust the exposure value.
Focus mode	Take close-up photos or set the camera to focus on the subject.
Timer	Select the length of the delay before the camera takes a photo.
Effects	Apply a special effect, such as sepia or grey-scale (black and white) tones.
Resolution	Change the resolution.
White balance	Adjust the color balance according to lighting conditions.
Metering	Select a type of exposure meter.
Outdoor visibility	Increase screen brightness to enhance visibility outdoors.

Option	Function
Guidelines	Display guidelines on the preview screen.
GPS tag	Set the camera to include location information for your photos. • To improve GPS signals, avoid shooting in locations where the signal may be obstructed, such as between buildings or in low-lying areas, or in poor weather conditions. • Your location may appear on your photos when you upload them to the web. To avoid this, deactivate the GPS tag setting.
Storage	Select a storage location for captured photos.
Reset	Reset menus and shooting options.

› Record a video

1 Open the application list and select **Camera** to turn on the camera.

2 Drag the slider to switch to the camcorder.

3 Aim the lens at the subject and make any necessary adjustments.

Number	Function
1	Use camcorder shortcuts. • : Change the flash setting. • : Switch to the front camera to record a video of yourself. • : Change the recording mode (for attaching to a message or for saving normally). • : Select the length of the delay before the camera recording a video. • : Adjust the exposure value. You can add or remove shortcuts to frequently used options. ► p. 66
2	Change the camcorder settings.
3	Check the camcorder status. • 02:30:30 : Length of video that can be recorded (according to available memory) • : Default storage location

Number	Function
4	Switch to the camera.
5	Record a video.
6	Open the image viewer to view photos or videos you captured or recorded.

4 Select to start recording.

5 Select to stop recording.
The video is saved automatically.

After recording videos, select the image viewer icon to view the recorded videos.

- To view more videos, scroll left or right. You can also tap the screen and scroll through the thumbnails of videos at the bottom of the screen.
- To play a video, select .
- To send a video to others, select **Share via**.
- To delete a video, select **Delete**.
- To access Gallery, select **Go to Gallery**.

› Customize camcorder settings

Before recording a video, select to access the following options:

Option	Function
Edit shortcuts	Edit shortcuts to frequently used options.
Self-recording	Switch between the front and rear camera.
Flash	Change the flash setting; You can manually turn the flash on or off.

Option	Function
Recording mode	Change the recording mode.
Exposure value	Adjust the exposure value.
Timer	Select the length of the delay before the camera starts recording a video.
Effects	Apply a special effect, such as sepia or grey-scale (black and white) tones.
Resolution	Change the resolution.
White balance	Adjust the color balance according to lighting conditions.
Outdoor visibility	Increase screen brightness to enhance visibility outdoors.
Guidelines	Display guidelines on the preview screen.
Storage	Select a storage location for recorded videos.
Reset	Reset menus and recording options.

› Edit the shortcut icons

You can add or remove shortcuts to frequently-used options.

1. From the preview screen, select ⚙ → **Edit shortcuts**.
2. Tap and hold an icon from the option list and drag it to the shortcut area.

   To remove shortcuts, tap and hold an icon and drag it to the option list.
3. Tap the screen to return to the preview screen.

Video player

Learn to use the video player to play various kinds of videos. The video player supports the following file formats: MP4, 3GP, AVI, WMV, ASF, MKV, FLV, WEBM.

- Avoid locking the device's screen while playing a DivX Video-On-Demand. Each time you lock the screen while playing a DivX Video-On-Demand, one of your available rental counts will be decremented.
- Playback quality may vary by content type.
- Some files may not play properly depending on how they are encoded.

1. Open the application list and select **Video player**.
2. Select a view mode at the top of the screen.
3. Select a video to play.
4. Control playback with the virtual keys.

While playing a video, use the following options:

- To send a video to others, select → **Share via**.
- To view the list of bookmarks, select → **Bookmarks**. This option appears only if you have bookmarked during playback by selecting .
- To display subtitles, select → **Subtitles**. This option appears only when a video supports a subtitle file.
- To apply a color effect, select → **Color tone**.
- To activate outdoor visibility to select an appropriate lighting condition, select → **Outdoor visibility**.
- To view video details, select → **Details**.

Gallery

Learn to view photos and play videos saved in your device's memory.

› Supported file formats

Type	Format
Image	• Extension: bmp, gif, jpg, png
Video	• Extension: 3gp (mp4), avi (divx), wmv (asf), flv, mkv, webm • Codec: MPEG4, H.263, H.264, VC-1, DivX®, VP8, WMV7/8, DivX3.11, Sorenson H.263

- Avoid locking the device's screen while playing a DivX Video-On-Demand. Each time you lock the screen while playing a DivX Video-On-Demand, one of your available rental counts will be decremented.
- Some file formats are not supported depending on the software of the device.
- If the file size exceeds the available memory, an error can occur when you open files.
- Playback quality may vary by content type.
- Some files may not play properly depending on how they are encoded.

› View a photo

1 Open the application list and select **Gallery**.

2 Select a folder.

To filter photos and videos, select → **Images and videos** → **Images only** or **Videos only**.

3 Select a photo to view.

Videos are indicated by the icon at the center; photos do not have an icon at the center.

While viewing a photo, use the following options:

- To view more photos, scroll left or right.
- To zoom in, place two fingers on the screen and spread them apart. To zoom out, move your fingers closer together. You can also double-tap the screen.

If you activated tilting motions, you can zoom in or out by tapping and holding two points with your fingers and then tilting the device back and forth.

- To start a slideshow of images, select . Tap the screen to stop the slideshow.
- To send a photo to others, select .
- To delete a photo, select .
- To view photo details, select → **Details**.
- To rotate a photo counter-clockwise, select → **Rotate left**.
- To rotate a photo clockwise, select → **Rotate right**.
- To set a photo as wallpaper or an image for a contact, select → **Set picture as**.
- To crop an image from a photo, select → **Crop**.
- To print a photo using a WLAN or USB connection, select → **Print**. Your device is compatible only with some Samsung printers.
- To copy a photo, select → **Copy**.
- To use motion recognition, select → **Motion**.

› Play a video

1 Open the application list and select **Gallery**.

2 Select a folder.

To filter photos and videos, select → **Images and videos** → an option.

3 Select a video (with the icon) to play.

4 Control playback with the virtual keys.

Photo editor

You can edit photos and apply various effects.

1 Open the application list and select **Photo editor**.

2 Tap a photo thumbnail image or select **Select picture** → a folder → an image.

You can create a new photo by selecting **Capture picture**.

3 To select an area of the image, select → **OK** and drag your finger over the area you want to select.

- To change the type of the selection tool, select .
- To add to or subtract from the selection border, select , , or . If you select **Grab**, you can adjust the selection size by selecting .
- To reverse the selection, select .

4 Select **Done**.

5 Use the following options to edit the photo:

Option	Function
	Rotate or flip the image.
	Resize the image by dragging the rectangle or selecting **100%** → an option.
	Crop the image by moving or dragging the rectangle.
	Apply a color effect.
	Apply a filter effect.
	Use additional tools.

- Select to undo your last action.
- Select to redo your last action.

6 Adjust the image as desired and select **Done**.

7 When you are finished, select .

8 Enter a name for the photo and select **OK**.

Personal information

Contacts

Learn to create and manage a list of your personal or business contacts. You can save names, mobile phone numbers, home phone numbers, email addresses, birthdays and more for your contacts.

› Create a contact

1. Open the application list and select **Contacts**.
2. Select +.
3. Select a storage location.
   If you have more than one account, select an account to which you want to add the contact.
4. Enter contact information.
5. Select **Done** to add the contact to memory.

› Retrieve contacts from messaging accounts

You can retrieve contacts by synchronizing your assigned account.

1. Open the application list and select **Contacts**.
2. Select → **View SNS friends**.
3. Select an account.
4. Select contacts → **Done**.
   An updated contact list is retrieved and saved on your device automatically.

› Find a contact

1. Open the application list and select **Contacts**.
2. Select **Search contacts** and enter the first few letter of a name.
3. Select the contact's name.

Once you find a contact, you can use the following options:

- To send an email message, select an email address.
- To edit the contact information, select → **Edit**.
- To delete the contact, select → **OK**.
- To add the contact to your favourites, select ★.

› Import or export contacts

To import contact files (in vcf format) from a memory card to your device,

1. Open the application list and select **Contacts**.
2. Select → **Import/Export** → **Import from SD card**.
3. Select a memory location.
   If you have more than one account, select an account to which you want to add the contacts.
4. Select an option for importing a single contact file, multiple contact files, or all contact files, and select **OK**.
5. Select contact files to import and select **OK**.

To export contacts from your device to a memory card,

1. Open the application list and select **Contacts**.
2. Select → **Import/Export** → **Export to SD card**.
3. Select **OK** to confirm.

› Create your namecard

1. Open the application list and select **Contacts**.
2. Select → **My profile**.
3. Select **Edit**.
4. Enter your personal details.
5. Select **Done**.

You can send your namecard by attaching it to an email or transferring it via the Bluetooth wireless feature.

› Create a group of contacts

1. Open the application list and select **Contacts**.
2. Select **Groups** → .
3. Enter a name for the group.
4. Select **Edit members**.
5. Select members from the contact list and select **Done**.
6. When you are finished, select **Done**.

Calendar

Learn to create and manage daily, weekly, or monthly events, and set alarms to remind yourself of important events.

› Change the calendar view

1. Open the application list and select **Calendar**.
2. Select a view mode from the top of the calendar.
   - **Day**: Hourly blocks for one full day
   - **Week**: Daily blocks for one full week
   - **Month**: Daily blocks for the current month
   - **List**: A list of all scheduled appointments

› Create an event

1. Open the application list and select **Calendar**.
2. Select +.
3. Enter the details of the event as required.
4. Select **Done**.

› View events

To view today's schedule,

1. Open the application list and select **Calendar**.
2. Select **Today**.
3. Select an event to view its details.

To view events for a specific date,

1. Open the application list and select **Calendar**.
2. Select a date on the calendar.
   To move to a specific day by entering a date manually, select → **Go to**, enter the date by selecting or and tapping the date, then select **Set**.
3. Select an event to view its details.

› Stop an event alarm

If you set an alarm for a calendar event, the event alarm icon will appear at the specified time.

1. Select on the system bar.
2. Select a reminder to view more details about the event.
3. To snooze or dismiss the reminder, select the check box next to events you want and select **Snooze** or **Dismiss**.

Memo

Learn to record important information to save and view at a later date.

› Create a memo

1. Open the application list and select **Memo**.
2. Select .
3. Enter your memo text.
4. Select **Done**.

› View memos

1 Open the application list and select **Memo**.

2 Select a memo to view its details.
To use additional features with a memo, select ◀.

Tool	Function
	Delete the memo.
	Change the background color of the memo.
	Lock the memo.
	Print the memo using a WLAN or USB connection. Your device is compatible only with some Samsung printers.
	Upload your memo on community websites.
	Send the memo to others.

Connectivity

PC connections

Learn to connect your device to a PC with a USB cable in various USB connection modes. By connecting the device to a PC, you can synchronize files with Windows Media Player, transfer data to and from your device directly, and use the Samsung Kies program.

To use PC connections, you must deactivate USB debugging mode. Open the application list and select **Settings** → **Applications** → **Development**, and then clear the check box next to **USB debugging**.

› Connect with Samsung Kies

Ensure that Samsung Kies is installed on your PC. You can download the program from the Samsung website (www.samsung.com/kies).

Samsung Kies will work on both Windows and Macintosh computers.

1. Using a USB cable, connect the multifunction jack on your device to a PC. Samsung Kies will launch automatically.
   If Samsung Kies does not launch automatically, double-click the Samsung Kies icon on your PC.
2. Copy files from the PC to the device.
   Refer to the Samsung Kies help for more information.

› Synchronize with Windows Media Player

Ensure that Windows Media Player is installed on your PC.

1. Using the USB cable, connect the multifunction jack on your device to a PC with Windows Media Player installed. When connected, a pop-up window will appear on the PC.
2. Open Windows Media Player to synchronize music files.
3. Edit or enter your device's name in the pop-up window (if necessary).
4. Select and drag the music files you want to the sync list.
5. Start synchronization.

› Connect as a mass storage device

You can connect your device to a PC as a removable disk and access the file directory. If you insert a memory card in the device, you can access the file directory of the memory card by using the device as a memory card reader.

The file directory of the memory card will appear as a removable disk, separate from the internal memory.

1. If you want to transfer files from or to a memory card, insert a memory card into the device.
2. Using the USB cable, connect the multifunction jack on your device to a PC.
3. Open the folder to view files.
4. Copy files from the PC to your device.

To disconnect the device from the PC, click the USB device icon on the Windows task bar and click the option to safely remove the mass storage device. Then remove the USB cable from the PC. Otherwise, you may lose data stored on your device or damage your device.

Wi-Fi

Learn to use your device's wireless networking capabilities to activate and connect to any wireless local area network (WLAN) compatible with the IEEE 802.11 a/b/g/n standards.

You can connect to the internet or other network devices anywhere an access point or wireless hotspot is available.

› Activate the WLAN feature

1 Open the application list and select **Settings** → **Wireless and networks**.

2 Select **Wi-Fi** to activate the WLAN feature.

An active WLAN running in the background will consume battery power. To preserve battery power, activate the WLAN only when needed.

› Find and connect to a WLAN

1 Open the application list and select **Settings** → **Wireless and networks** → **Wi-Fi settings**.
The device will automatically search for available WLANs.

2 Select a network under **Wi-Fi networks**.

3 Enter a password for the network (if necessary).

4 Select **OK**.

› Add a WLAN manually

1. Open the application list and select **Settings** → **Wireless and networks** → **Wi-Fi settings** → **Add Wi-Fi network**.
2. Enter the SSID for the network and select the security type.
3. Set the security settings depending on the selected security type.
4. Select **Save**.

› Connect to a WLAN using a Wi-Fi Protected Setup (WPS)

Using WPS, you can connect to a secured network.

To connect to a WLAN on a WPS-enabled access point,

1. Open the application list and select **Settings** → **Wireless and networks** → **Wi-Fi settings**.
2. Select a network indicated as WPS available and select the drop-down menu next to **Network Setup**.
3. Select **WPS push button** → **OK**.
4. Press the WPS button on the access point within 2 minutes.

To connect to a WLAN with a WPS PIN,

1. Open the application list and select **Settings** → **Wireless and networks** → **Wi-Fi settings**.
2. Select a network indicated as WPS available and select the drop-down menu next to **Network Setup**.

3 Select **WPS pin from this device** → **OK**. On the access point, enter the PIN shown on the tablet and press the start button.

Or, select **WPS pin from access point**, enter the PIN shown on the access point, and press **OK**.

› Set static IP settings

1 Open the application list and select **Settings** → **Wireless and networks** → **Wi-Fi settings**.

2 Select an access point on the network list.

3 Select the drop-down menu next to **IP settings**.

4 Select **Static**.

5 Change the IP settings for the access point as required (IP address, Gateway, Network prefix length, DNS).

6 Select **OK**.

Wi-Fi Direct

Learn to use the Wi-Fi Direct feature to connect two devices via a WLAN without requiring an access point.

› Connect your device to another device

1 Open the application list and select **Settings** → **Wireless and networks** → **Wi-Fi Direct settings** → **OK** → **Wi-Fi Direct**.

2 Select → **Scan**.

3 Select a device and then select **Connect**.

When the connection is accepted on the other device, the devices are connected.

› Send data via a WLAN

1 Select a file or item, such as a memo, media file, or web address, from an appropriate application or My files.

2 Select an option for sending data via a WLAN.

The method for selecting an option may vary by data type.

3 Search for and select another device.

› Receive data via a WLAN

When prompted, select **OK** to confirm that you are willing to receive data. Received data is saved to the ShareViaWifi folder.

Bluetooth

Bluetooth is a short-range wireless communications technology capable of exchanging information over a distance of about 10 m without requiring a physical connection.

You do not need to line up the devices to beam information with Bluetooth. If the devices are within range of one another, you can exchange information between them even if they are located in different rooms.

- Samsung is not responsible for the loss, interception, or misuse of data sent or received via the Bluetooth wireless feature.
- Always ensure that you share and receive data with devices that are trusted and properly secured.
- If there are obstacles between the devices, the operating distance may be reduced.
- Some devices, especially those that are not tested or approved by Bluetooth SIG, may be incompatible with your device.

› Turn on the Bluetooth wireless feature

1 Open the application list and select **Settings** → **Wireless and networks**.

2 Select **Bluetooth** to turn on the Bluetooth wireless feature.

› Find and pair with other Bluetooth-enabled devices

1 Open the application list and select **Settings** → **Wireless and networks** → **Bluetooth settings** → **Scan for nearby devices**.

2 Select a device.

3 Enter a PIN for the Bluetooth wireless feature or the other device's Bluetooth PIN, if it has one, and select **OK**. Alternatively, select **Accept** to match the PIN between your device and the device.

When the PIN is entered or connection accepted on the other device, pairing is complete. If the pairing is successful, the device will automatically search for available services.

Some devices, especially headsets or hands-free car kits, may have a fixed Bluetooth PIN, such as 0000. If the other device has a PIN, you must enter it.

› Send data using the Bluetooth wireless feature

1 Select a file or item, such as a contact, calendar event, memo, or media file, from an appropriate application.

2 Select an option for sending data via Bluetooth.

The method for selecting an option may vary by data type.

3 Search for and pair with a Bluetooth-enabled device.

› Receive data using the Bluetooth wireless feature

1 Open the application list and select **Settings** → **Wireless and networks** → **Bluetooth settings** → **Visible**.

2 When prompted, enter the PIN for the Bluetooth wireless feature and select **OK** (if necessary).

3 Select on the system bar and select **Accept** to confirm that you are willing to receive data from the device.

Received data is saved to the bluetooth folder. If you receive a contact file, select **My files** → **bluetooth** → a contact file to import it to your contact list.

AllShare

Learn to use the Digital Living Network Alliance (DLNA) service that enables you to share media files between DLNA-enabled devices in your home over a WLAN.

You must first activate the WLAN feature and add a WLAN profile. ► p. 81

- The supported file formats may vary depending on the software of the device.
- Some files may not play on the DLNA- enabled devices depending on the devices.

› Customize DLNA settings for sharing media files

To allow other DLNA-enabled devices to access media files on your device, you must activate media sharing.

1. Open the application list and select **AllShare**.
2. Select .
3. Adjust the following settings to customize the DLNA feature:

Option	Function
Media server name	Enter a name for your device as a media server.
Share media	Turn on video, image, and music sharing with other DLNA-enabled devices.
Access point network	Select a connection profile to use for DLNA connections.
Upload from other devices	Set whether or not to accept the upload from other devices.
Default memory	Select the default memory location for saving downloaded media files.

› Play your files on another DLNA-enabled device

1. Open the application list and select **AllShare**.
2. Select **My device**.
3. Select a media category → files.

4 Select a player—the one that will play the media file. Playback begins at the selected player.

5 Control playback using icons of your device.

Playback may be buffered, depending on the network connection and the connected server.

› Play others' files on your device

1 Open the application list and select **AllShare**.

2 Select a device as the media server—the one that contains media files.

3 Select a media category → files.
Playback begins at the selected player.

4 Control playback using icons of your device.

› Play files of one device on the other device

1 Open the application list and select **AllShare**.

2 Select a device as the media server—the one that contains media files.

3 Select a media category → files.
Playback begins at the selected player.

4 Select .
Your device automatically searches for DLNA-enabled devices.

5 Select a player—the one that will play the media file.

6 Control playback using icons of your device.

GPS

Your device is equipped with a global positioning system (GPS) receiver. Learn to activate location services.

To receive better GPS signals, avoid using your device in the following conditions:

- between buildings, in tunnels or underground passages, or inside buildings
- in poor weather
- around high voltage or electromagnetic fields
- in a vehicle with sun protection film

Do not touch the internal antenna area or cover this area with your hands or other objects while using the GPS functions.

This feature may be unavailable depending on your region or service provider.

› Activate location services

You must activate location services to receive location information and search the map.

1 Open the application list and select **Settings** → **Location and security**.

2 Adjust the following settings to activate location services:

Option	Function
Use wireless networks	Set to use WLANs for finding your location.
Use GPS satellites	Set to use the GPS satellite for finding your location.

Option	Function
Use location data for Google search	Set the device to use your current location for Google search and other Google services.

VPN connections

You can create virtual private networks (VPN) and connect to your private network securely through a public network, such as the internet.

Your device should already be configured with internet access. If you have trouble accessing the internet, you need to edit connections. If you are not sure about the connection information to enter, ask your service provider.

› Set up VPN connections

1. Open the application list and select **Settings** → **Wireless and networks** → **VPN settings** → **Add VPN**.
2. Select a VPN type.
3. Customize the connection information.

Available options may vary depending on the VPN type.

Option	Function
VPN name	Enter a name of the VPN server.
Set VPN server	Enter the IP address of the VPN server.
Enable Encryption	Set to encrypt the VPN server.

Option	Function
Set IPsec pre-shared key	Enter a pre-shared key.
Enable L2TP secret	Set to use the L2TP secret password.
Set L2TP security	Enter the L2TP secret password.
Set user certificate	Select a user certificate that the VPN server uses to identify you. You can import certificates from the VPN server or download from the web.
Set CA certificate	Select a certificate authority (CA) certificate that the VPN server uses to identify you. You can import certificates from the VPN server or download from the web.
DNS search domains	Enter the domain name server (DNS) address.

4 When you are finished, select → **Save**.

› Connect to a private network

1 Open the application list and select **Settings** → **Wireless and networks** → **VPN settings**.

2 Select a private network to connect.

3 Enter the user name and password and select **Connect**.

Settings

Access the Settings menu

1 Open the application list and select **Settings**.
2 Select a setting category and select an option.

Wireless and networks

Change the settings for wireless network connections.

› Airplane mode

Disable all wireless functions on your device. You can use only non-network services.

› Wi-Fi

Turn the WLAN feature on or off.

› Wi-Fi settings

- **Wi-Fi**: Turn the WLAN feature on or off. ► p. 81
- **Network notification**: Set the device to notify you when an open network is available.
- **Wi-Fi sleep policy**: Set when the device will turn off the WLAN feature.
- **Add Wi-Fi network**: Add WLAN APs manually.

› Wi-Fi Direct settings

- **Wi-Fi Direct**: Activate the Wi-Fi Direct feature to connect two devices via a WLAN without requiring an access point. ► p. 83
- **Device name**: View or edit your device's name.
- **Status**: View the connection status.
- **Disconnect Wi-Fi Direct**: Deactivate the Wi-Fi Direct feature.

› Kies via Wi-Fi

Connect your device to Samsung Kies via a WLAN.

› Bluetooth

Turn the Bluetooth wireless feature on or off.

› Bluetooth settings

- **Bluetooth**: Turn the Bluetooth wireless feature on or off. ► p. 84
- **Device name**: Set a Bluetooth name for your device.
- **Visible**: Set your device to be visible to other Bluetooth devices.
- **Visible time-out**: Set duration that your device is visible.
- **Show received files**: View files received from other devices via the Bluetooth wireless feature.
- **Scan for nearby devices**: Search for available Bluetooth devices.

› VPN settings

Set up and connect to virtual private networks (VPNs).
► p. 90

Sound

Change the settings for various sounds on your device.

- **Vibrate**: Set when the device will vibrate for various events.
- **Volume**: Adjust the volume level for notifications, media sounds, alarm ringtones, and system sounds.
- **Vibration intensity**: Adjust the vibration intensity of the notification and haptic feedback.
- **Notification ringtone**: Select a ringtone to alert you to events.
- **Audible selection**: Set the device to sound when you select an application or option on the touch screen.
- **Screen lock sounds**: Set the device to sound when you lock or unlock the touch screen.
- **Haptic feedback**: Set the device to vibrate when you touch the keys.

Screen

Change the settings for the display.

- **Brightness**: Activate the automatic brightness or set the brightness of the display.
- **Screen display**:
  - **Font style**: Change the font type for the display text. You can download fonts from Android Market by selecting **Get fonts online**.
  - **Home screen**:
    Wallpaper: Select a background image for the Home screen.
  - **Lock screen**:
    Wallpaper: Select an image to display when the screen is locked.

- **Mode**: Select a display mode.
- **Auto-rotate screen**: Set whether or not to rotate the content automatically when the device is rotated.
- **Animation**: Set the device to display animation when you switch between windows.
- **Timeout**: Set the length of time the device waits before turning off the display when it is inactive.
- **Quick launch**: Change the Quick launch application. The default is Screen capture (launched by selecting). The other options are launched by selecting .
- **Auto adjust screen power**: Set to save power by adjusting the brightness of the display.
- **Horizontal calibration**: Calibrate the accelerometer to adjust the horizontal axis of the device for better motion recognition.

Power saving mode

- **Use Custom power saving**: Automatically activate Power saving mode when the battery is low.
- **Custom power saving settings**:
  - **Power saving mode on**: Select a power level for Power saving mode.
  - **Turn off Wi-Fi**: Deactivate the WLAN feature when the device is not connected with a WLAN AP.
  - **Turn off Bluetooth**: Deactivate the Bluetooth feature when not in use.
  - **Turn off GPS**: Deactivate the GPS feature when not in use.
  - **Turn off Sync**: Turn off sync when the device is not synchronizing with a web server.
  - **Brightness**: Activate the brightness setting for Power saving mode.

- **Brightness**: Set the brightness level for Power saving mode.
- **Timeout**: Set the length of time the device waits before turning off the display's backlight.

- **Learn about power saving**: Learn how to reduce battery consumption.

Location and security

Change the settings for securing your device and GPS functionality.

- **Use wireless networks**: Set to use WLANs for finding your location.
- **Use GPS satellites**: Set to use the GPS satellite for finding your location.
- **Use location data for Google search**: Set the device to use your current location for Google search and other Google services.
- **Configure lock screen**: Set how to unlock the screen.
  - **Off**: Disable the screen lock.
  - **Unsecure**: Set to use the screen lock without a PIN, password, or pattern.
  - **Pattern**: Set an unlock pattern to unlock the screen.
  - **PIN**: Set a PIN (numeric) to unlock the screen.
  - **Password**: Set a password (alphanumeric) to unlock the screen.
- **Owner information**: Edit the text you want to display on the screen in Screen lock mode.

- **Encrypt device**: Set a PIN or a password to encrypt the device to protect data and information saved on the device. Once the device is encrypted, you must enter the password each time you turn on the device. Ensure the battery is fully charged or the device is connected to the charger because it may take more than an hour to encrypt your device.
- **Encrypt SD card**:
  - **Encrypt SD card**: Protect your personal information by encrypting the data on your memory card.
  - **Full encryption**: Set to encrypt all files on your memory card.
  - **Exclude multimedia files**: Set to encrypt all files except multimedia files on your memory card.

You cannot access the encrypted memory card after a factory data reset. Decode the memory card before performing a factory data reset.

- **Remote controls**: Set to control a lost device remotely via the web.
- **Visible passwords**: Set the device to display your password as you enter.
- **Device administrators**: View device administrators installed on your device. You can activate device administrators to apply new policies to your device.
- **Use secure credentials**: Use certificates and credentials to ensure secure use of various applications.
- **Install from USB storage**: Install encrypted certificates from USB storage.
- **Set password**: Create and confirm a password for accessing credentials.
- **Clear storage**: Erase the credential contents from the device and reset the password.

Applications

Change the settings for managing installed applications.

- **Manage applications**: Access the list of the applications installed on the device and check the application information.
- **Running services**: View and control currently running services.
- **Memory usage**: View available memory and the memory used by applications.
- **Battery use**: View the amount of power consumed by various components of your device.
- **Unknown sources**: Select to download applications from any source. If you do not select this option, you can download applications only from Android Market.
- **Development**:
  - **USB debugging**: This feature is used for development purposes only. It turns on Debug mode when USB is connected.
  - **Stay awake**: Set the device's screen to stay on while charging the battery.
  - **Allow mock locations**: This feature is used for development purposes only. It allows the entry of "mock" GPS coordinates in order to test GPS applications.
- **Samsung Apps**:
  - **New application notification**: Set to receive notifications for new applications from Samsung Apps.
  - **Reset locale**: Deletes locale information.

This feature may be unavailable depending on your region or service provider.

Accounts and sync

Change the settings for the auto sync feature or manage accounts for synchronization.

- **Background data**: Select this setting to use the auto sync feature. The auto sync will run in the background without opening applications and synchronize data.
- **Auto-sync**: Set the device to synchronize contact, calendar, and email data automatically.

Motion

Change the settings that control motion recognition on your device.

- **Motion activation**: Set to use motion recognition.
- **Tilt to zoom**: Set to zoom in or out while viewing images in Gallery or browsing web pages when you tap and hold two points with your fingers and then tilt the device back and forth.
- **Pan to edit**: Set to move an icon to another page when you tap and hold the icon and then pan the device to the left or right.

Privacy

Change the settings for managing your settings and data.

- **Back up my data**: Set to back up your settings and application data to the Google server.
- **Backup account**: select an account to back up your data.

- **Automatic restore**: Set to restore your settings and application data when the applications are reinstalled on your device.
- **Factory data reset**: Reset your settings to the factory default values and delete all your data.

Storage

View memory information for your device and memory card. You can also format the memory card. ►p. 13

Formatting a memory card will permanently delete all data from the memory card.

Language and input

Change the settings for text input, the voice recognizer, and the text-to-speech feature.

› Select language

Select a display language for all menus and applications.

› Voice recognition settings

- **Language**: Select a language for the Google voice recognition.
- **SafeSearch**: Set the device to filter explicit text and/or images from voice search results.
- **Block offensive words**: Hide offensive words your device recognized from voice search results.

› Text-to-speech settings

- **Listen to example**: Listen to the spoken text for an example.
- **Always use my settings**: Set to use the speech rate and language settings you specify over the settings saved in applications.
- **Default engine**: Set the speech synthesis engine to be used for spoken text.
- **Install voice data**: Download and install voice data for the text-to-speech feature.
- **Speech rate**: Select a speed for the text-to-speech feature.
- **Language**: Select a language for the text-to-speech feature.
- **Engines**: View the text-to-speech engines in your device.

› Current input method

Select a default keyboard type for text input.

› Input method selector

Set the device to hide or display the text input settings icon (⌨). If you select **Automatic**, your device will automatically hide or display the icon, based on the keyboard.

› Configure input methods

- **Swype**
  - **Swype**: Set the device to use the Swype keyboard.
  - **Settings**:
    Select Input Method: Change the keyboard type.
    How to Swype: Learn how to enter text with the Swype keyboard.

Personal dictionary: Set up your own dictionary. The words in your dictionary will appear as suggestions for your text inputs.

Preferences:

- **Audio feedback**: Set to alert you when there are no alternative words for your input if you double-tap a word.
- **Vibrate on keypress**: Set the device to vibrate when you touch a key.
- **Show tips**: Set the device to automatically display tips for your actions when available.
- **Auto-spacing**: Set the device to automatically insert a space between words.
- **Auto-capitalization**: Set the device to automatically capitalize the first letter after a final punctuation mark, such as a full stop, question mark, or exclamation mark.
- **Show complete trace**: Set to display the trace of your dragging on the keyboard.
- **Word suggestion**: Set the device to display suggestions while you are entering text. This feature is available only for English.
- **Speed vs. accuracy**: Set the balance for the speed and accuracy.
- **Reset Swype's dictionary**: Delete the words you have added to the dictionary.
- **Version**: View version information.

Language Options: Select a language for text input.

You cannot enter text in some languages. To enter text, you should change the writing language to one of the supported languages.

- **Android keyboard**
  - **Android keyboard**: Set the device to use the Android keyboard.
  - **Active input methods**: Select languages for text input.
  - **Settings**:
    Auto-capitalization: Set the device to automatically capitalize the first letter after a final punctuation mark, such as a full stop, question mark, or exclamation mark.
    Vibrate on key-press: Set the device to vibrate when you touch a key.
    Sound on key-press: Set the device to sound when you touch a key.
    Show settings key: Set whether to show the settings key.
    Auto-correction: Set the device to automatically correct the misspelled words.
    Show correction suggestions: Set the device to predict words according to your input and display word suggestions.
- **Samsung keypad**
  - **Samsung keypad**: Set the device to use the Samsung keyboard.
  - **Settings**:
    Input language: Select languages for text input.
    XT9: Activate XT9 mode to enter text using Predictive input mode.
    XT9 advanced settings: Activate the advanced features of XT9 mode, such as word completion, spell correction, or auto-substitution, and set up your own word list.
    Automatic period: Set the device to insert a period when you double-tap the space bar.

Sound on keypress: Set the device to sound when you touch a key.

Auto-capitalization: Set the device to automatically capitalize the first letter after a final punctuation mark, such as a full stop, question mark, or exclamation mark.

Voice input: Activate the voice input feature to enter text by voice on the Samsung keypad.

Handwriting settings: Customize the settings for Handwriting mode, such as recognition time, pen thickness or pen color.

Tutorial: Learn how to enter text with the Samsung keypad.

Accessibility

Change the settings for accessibility features.

- **Accessibility**: Activate included and downloaded accessibility applications, such as Talkback and Kickback, which provide voice, melody, or vibration feedback.
- **Accessibility applications**: Select an accessibility application to use.
- **Accessibility scripts**: Set to allow downloading of accessibility scripts from Google.
- **Tap and hold delay**: Set the recognition time for tapping and holding the screen.
- **Torch light**: Turn the torch light on or off.
- **Mono audio**: Enable mono sound when you listen to audio with one earbud.
- **Accessibility shortcut**: Add a shortcut to Accessibility settings on the quick menu that appears when you press and hold [⏻].

Date and time

Access and alter the following settings to control how time and date are displayed on your device.

If the battery is fully discharged, the time and date will be reset.

- **Set date**: Set the current date.
- **Set time**: Set the current time.
- **Select time zone**: Set your home time zone.
- **Use 24-hour format**: Set to the time to be displayed in 24-hour format.
- **Select date format**: Select a date format.

About device

Access information about your device, check the device's status, and update the device system.

Tools

Alarm

Learn to set and control alarms for important events.

› Set a new alarm

1. Open the application list and select **Alarm**.
2. Select +.
3. Set alarm details.
4. When you are finished, select **Done**.

› Stop an alarm

When the alarm sounds,

- To stop the alarm, drag ⊠ in any direction until it reaches the border of the circle.
- To repeat the alarm after a preset delay, drag zz in any direction until it reaches the border of the circle.

› Delete an alarm

1. Open the application list and select **Alarm**.
2. Select an alarm to delete.
3. Select **Delete** → **OK**.

You can delete or deactivate alarms by tapping and holding an alarm and selecting **Delete alarm** or **Deactivate alarm**.

Calculator

Learn to perform mathematical calculations directly on your device like a typical hand-held or desktop calculator.

1. Open the application list and select **Calculator**.
2. Use the keys that correspond to the calculator display to perform a basic or scientific calculation.

Downloads

View and manage logs of files you have downloaded from the web.

1. Open the application list and select **Downloads**.
2. Select a download folder.
3. To open a downloaded file, select the log.
   To delete a log, select the check box and then select .

eBook

Learn to open and read books and PDF files.

› Read books

1. Open the application list and select **eBook**.
2. If you are launching this application for the first time, read the disclaimer and select **Confirm**.
3. Select a book from the bookshelf.

4 To move pages, drag your finger left or right or tap near the left or right margin of a page.

5 Tap the screen and use the following options:

- To view the table of contents, bookmarks, highlights, memos, drawings and information, select .
- To customize the settings for fonts and theme, select .
- To read a book via text-to-speech feature, select → **Read**.
- To search for text in the book, select .
- To bookmark the current page, select .
- To copy a word, tap and hold a word and select **Copy** from the pop-up window.
- To highlight a word, tap and hold a word and select **Highlight** from the pop-up window.
- To add a memo, tap and hold a word and select **Memo** from the pop-up window.
- To search a word on the web, tap and hold a word and select **Search** from the pop-up window.

6 Create a drawing memo with the following tools:

Tool	Function
	Highlight the text.
	Draw on the book.
	Erase the drawing or highlight.
	Customize the pen and highlight settings.

› Import book files

You can import book files (in epub and pdf format) from the internal memory.

- Some DRM-protected book files are not supported.
- You can purchase a book via online bookstore by selecting .

1. Open the application list and select **eBook**.
2. Select → **Import**.
3. Select book files to import and select **Done**.

Google Search

You can search for applications and files in your device and specific data on the web.

1. Open the application list and select **Google Search**.
2. Enter a letter or a word of the data to search for.
   To search for information by voice, select .
3. Select the item's name you want to access.

My files

Learn to quickly and easily access all of your images, videos, music, sound clips, and other types of files stored on your device.

› Supported file formats

Type	Format
Image	• Extension: bmp, gif, jpg, png
Video	• Extension: 3gp (mp4), avi (divx), wmv (asf), flv, mkv, webm • Codec: MPEG4, H.263, H.264, VC-1, DivX®, VP8, WMV7/8, DivX3.11, Sorenson H.263
Music	• Extension: mp3, aac, ogg, wma, amr, m4a, mp4, flac, wav, mid, mxmf, xmf, rtttl, rtx, ota, imy • Codec: MP3, AAC, AAC+, eAAC+, FLAC, WMA, Vorbis, Midi, AMR NB/WB, AC3 (only with Video), WAV

- Avoid locking the device's screen while playing a DivX Video-On-Demand. Each time you lock the screen while playing a DivX Video-On-Demand, one of your available rental counts will be decremented.
- Some file formats are not supported depending on the software of the device.
- If the file size exceeds the available memory, an error can occur when you open files.
- Playback quality may vary by content type.
- Some files may not play properly depending on how they are encoded.

› Open a file

1 Open the application list and select **My files**.

2 Select the drop-down menu at the upper right of the screen and select an option to sort the file list.

3 Select a folder.
   - To move up one level in the file directory, select .
   - To return to the top level of the file directory, select .
4 Select a file to open.

› Create a folder

1 Open the application list and select **My files**.
2 Select .
3 Enter a name and select **Done**.

› Copy or move files

1 Open the application list and select **My files**.
2 Select a check box next to folders or files to copy or cut.
3 Select or .
4 Locate a folder and select .

› Send files

1 Open the application list and select **My files**.
2 Select a check box next to files to send.
3 Select → an option.

› Delete files

1 Open the application list and select **My files**.
2 Select a check box next to folders or files to delete.
3 Select → **Yes**.

Pen memo

Learn to create sketch memos with various tools.

1 Open the application list and select **Pen memo**.

2 Select .

3 Create a drawing memo with the following tools:

Tool	Function
	Enter your text.
	Write or draw on the screen.
	Erase the sketch.
	Customize the tool settings.

You can also use the following options:

- To insert a photo, memo or map, select → **Insert**.
- Select to undo your last action.
- Select to redo your last action.

4 When you are finished, select **Done**.

Polaris Office

Learn to create or view Microsoft Word, Excel, PowerPoint, and Adobe PDF files on your device.

› Create a new document

1 Open the application list and select **Polaris Office**.

2 If you are launching this application for the first time, register as an online user or skip the registration.

3 Select **New File** → a document type.

4 Enter contents in the document.

5 When you are finished, select .

6 Enter a name for the document and select the location to save the document.

7 Select **Save**.

› Open a document

1 Open the application list and select **Polaris Office**.

2 Select **Local Storage** → a document file.
To open a recently saved file, select a file under **Recent Files**.

3 View or edit the document as desired.

Available options may vary depending on a document type.

- To open the toolbar to edit the file (Document, Sheet or Slide file), select .
- To zoom in, place two fingers on the screen and spread them apart. To zoom out, move your fingers closer together. You can also select → **Zoom In/Out**.
- To search for text on the document, select → **Find**. You can also select in landscape view.
- To bookmark the current page, select → **Bookclip**.
- To adjust the document to fit the screen, select → **Reflow text**.
- To send a file to others, select → **Send**.
- To read the document via the text-to-speech feature, select → **Text to speech**.
- To print the file using a WLAN or USB connection, select → **Print**. Your device is compatible only with some Samsung printers.

› Manage documents online

To use a Box.net account to store documents online,

1. Open the application list and select **Polaris Office**.
2. Select **Add Account**.
3. Enter your Email address and password to access your Box.net account, and then select **OK**.

To manage documents,

1. Open the application list and select **Polaris Office**.
2. Select **Web Storage** → an account.
3. View and manage your documents on the server as desired.

Voice Search

Learn to use the voice command feature to search for locations and information by voice.

This feature may be unavailable depending on your region or service provider.

1. Open the application list and select **Voice Search**.
2. Select **Speak now** (if necessary).
3. Say a command into the microphone.

World Clock

Learn to view the time in another region.

1. Open the application list and select **World Clock**.
2. Select +.
3. Enter a city name and select a city from the list. You can select a city in the world map view.
4. Select +.

5 To add more world clocks, repeat steps 2-4.

To apply Daylight Savings Time, tap and hold a clock and select **DST settings**.

Troubleshooting

Your device displays network or service error messages

- When you are in areas with weak signals or poor reception, you may lose reception. Move to another area and try again.
- You cannot access some options without a subscription. Contact your service provider for more details.

The touch screen responds slowly or improperly

If your device has a touch screen and the touch screen is not responding properly, try the following:

- Remove any protective covers from the touch screen. Protective covers may prevent the device from recognising your inputs and are not recommended for touch screen devices.
- Ensure that your hands are clean and dry when tapping the touch screen.
- Restart your device to clear any temporary software bugs.
- Ensure that your device software is upgraded to the latest version.
- If the touch screen is scratched or damaged, take it to your local Samsung Service Centre.

Your device freezes or has fatal errors

If your device freezes or hangs, you may need to close programs or reset the device to regain functionality. If your device is frozen and unresponsive, press and hold [⏻] for 10-15 seconds. The device will reboot automatically.

If this does not solve the problem, perform a factory data reset. Open the application list and select **Settings** → **Privacy** → **Factory data reset** → **Reset device** → **Erase everything**.

The device beeps and the battery icon is empty

Your battery is low. Recharge the battery to continue using the device.

The battery does not charge properly or the device turns off

If the battery will no longer charge completely, you need to replace it with a new battery. Take your device to your local Samsung Service Centre.

Your device is hot to the touch

When you use applications that require more power or use applications on your device for an extended period of time, your device may feel hot to the touch. This is normal and should not affect your device's lifespan or performance.

Error messages appear when launching the camera

Your Samsung mobile device must have sufficient available memory and battery power to operate the camera application. If you receive error messages when launching the camera, try the following:

- Charge the battery.
- Free some memory by transferring files to a PC or deleting files from your device.
- Restart the device. If you are still having trouble with the camera application after trying these tips, contact a Samsung Service Centre.

Error messages appear when opening music files

Some music files may not play on your Samsung mobile device for a variety of reasons. If you receive error messages when opening music files on your device, try the following:

- Free some memory by transferring files to a PC or deleting files from your device.
- Ensure that the music file is not Digital Rights Management (DRM)-protected. If the file is DRM-protected, ensure that you have the appropriate license or key to play the file.
- Ensure that your device supports the file type.

Another Bluetooth device is not located

- Ensure that the Bluetooth wireless feature is activated on your device.
- Ensure that the Bluetooth wireless feature is activated on the device you wish to connect to, if necessary.
- Ensure that your device and the other Bluetooth device are within the maximum Bluetooth range (10 m).

If the tips above do not solve the problem, contact a Samsung Service Centre.

A connection is not established when you connect the device to a PC

- Ensure that the USB cable you are using is compatible with your device.
- Ensure that you have the proper drivers installed and updated on your PC.

Index

Airplane mode 16
alarms
  creating 106
  deactivating 106
  deleting 106
  stopping 106
AllShare 87
application list
  accessing 27
battery
  charging 10
Bluetooth
  activating 85
  finding and pairing with devices 85
  receiving data 86
  sending data 85
brightness, display 30
browser
  adding bookmarks 40
  browsing web pages 37
  opening multiple pages 39
  searching for information by voice 39
calendar
  creating events 76
  viewing events 76
camera
  capturing photos 59
  customizing camcorder 66
  customizing camera 63
  recording videos 64
connections
  Bluetooth 84
  PC 79
  VPN 90
  WLAN 81
contacts
  creating 73
  retrieving 73
device
  customizing 28
  indicator icons 20
  keys 19
  layout 17
  notifications panel 26
  settings 92
  turning on or off 16
download manager 107
eBook 107
  importing 109
email
  sending 51
  viewing 52
file manager
  copying or cutting files 111
  deleting files 111
  opening files 110
  supported file formats 110
gallery
  playing videos 71
  viewing photos 70
Gmail 49
Google Latitude 45

Google Maps 43
Google Play 42
Google Talk 53
home screen
adding items 25
moving items 25
removing items 25
language 100
map 43
getting directions 44
searching for locations 44
searching for nearby places 46
sharing locations with friends 45
using navigation 46
memory card
formatting 15
inserting 13
removing 14
memos
creating 77
viewing 78
messages
sending email 51
setting email accounts 51
music player
adding files 56
creating playlists 57
playing music 57
navigation 46
PC connections
mass storage 80
Samsung Kies 79
Windows Media Player 80
phonebook
creating contacts 73
finding contacts 74
photo editor 71
photos
capturing 59
capturing by scene 60
viewing 70
Play Store 42
Polaris Office 112
Pulse 41
Samsung Apps 47
Samsung Hub 48
Samsung Kies 79
settings
about device 105
accessibility 104
accounts and sync 99
applications 98
date and time 105
language and input 100
location and security 96
power saving mode 95
privacy 99
screen 94
sound 94
storage 100
wireless and networks 92
silent mode 28
sketch memo 112
text input 31
text memos 77

time and date, set 28
touch screen
locking 22
using 21
unpack 10
video player 71
videos
playing 68, 71
recording 64
voice search 114
VPN connections
connecting to 91
creating 90
Web 37
WLAN
activating 81
finding and connecting to networks 81
using WPS 82
world clock 114
YouTube 43
uploading videos 43
watching videos 43